

SYT96E 200/5A 120 Kvar

SYT96E 200/5A 120 Kvar, Scale

Code: M132KF. **DESCATALOGADO**

> System: Three-phase
> Measurement Range (A): 200/5
> Full scale: 120 kvar
> Device: SYT96E
> Modules: 96x96

Specifications

Mechanical characteristics

Size (mm) width x height x depth	84 x 84 x 1 (mm)
Weight (kg)	0,008

SYM/SYT
YMC/YTC varmeter

CODE	TYPE	Measurement Range (A)	Modules	Device	Full scale
M132J9.	SYM96 50/5A 20 kvar	50/5	96x96	SYM96	20 kvar
M132JC.	SYM96 100/5A 40 kvar	100/5	96x96	SYM96	40 kvar
M132JE.	SYM96 150/5A 60 kvar	150/5	96x96	SYM96	60 kvar
M132JF.	SYM96 200/5A 80 kvar	200/5	96x96	SYM96	80 kvar
M132JH.	SYM96 300/5A 120 kvar	300/5	96x96	SYM96	120 kvar
M132JJ.	SYM96 400/5A 160 kvar	400/5	96x96	SYM96	160 kvar
M132JK.	SYM96 500/5A 200 kvar	500/5	96x96	SYM96	200 kvar
M132JL.	SYM96 600/5A 240 kvar	600/5	96x96	SYM96	240 kvar
M132JP.	SYM96 1000/5A 400 kvar	1000/5	96x96	SYM96	400 kvar
M132JR.	SYM96 1500/5A 600 kvar	1500/5	96x96	SYM96	600 kvar
M132JS.	SYM96 2000/5A 800 kvar	2000/5	96x96	SYM96	800 kvar
M132JU.	SYM96 3000/5A 1,2 Mvar	3000/5	96x96	SYM96	1,2 Mvar
M132JV.	SYM96 4000/5A 1,6 Mvar	4000/5	96x96	SYM96	1,6 Mvar
M132JW.	SYM96 5000/5A 2,0 Mvar	5000/5	96x96	SYM96	2,0 Mvar
M132K9.	SYT96E 50/5A 30 Kvar	50/5	96x96	SYT96E	30 kvar
M132KB.	SYT96E 75/5A 50 Kvar	75/5	96x96	SYT96E	50 kvar
M132KC.	SYT96E 100/5A 60 Kvar	100/5	96x96	SYT96E	60 kvar
M132KE.	SYT96E 150/5A 90 Kvar	150/5	96x96	SYT96E	90 kvar
M132KF.	SYT96E 200/5A 120 Kvar	200/5	96x96	SYT96E	120 kvar
M132KH.	SYT96E 300/5A 180 Kvar	300/5	96x96	SYT96E	180 kvar
M132KJ.	SYT96E 400/5A 240 Kvar	400/5	96x96	SYT96E	240 kvar
M132KK.	SYT96E 500/5A 300 Kvar	500/5	96x96	SYT96E	300 kvar
M132KL.	SYT96E 600/5A 360 Kvar	600/5	96x96	SYT96E	360 kvar
M132KP.	SYT96E 1000/5 600 Kvar	1000/5	96x96	SYT96E	600 kvar

Creation date: 01/09/2026 - CIRCUTOR, SAU reserves the right to make technical changes or modify the content/images of this document without prior notice, in order to improve its reliability, functionality, design or for other reasons.
It accepts no liability for any errors, inaccuracies or possible lack of information in this document.



SYT96E 200/5A 120 Kvar

Code: M132KF.

CODE	TYPE	Measurement Range (A)	Modules	Device	Full scale
M132KR.	SYT96E 1500/5 900 Kvar	1500/5	96x96	SYT96E	900 kvar
M132KS.	SYT96E 2000/5 1,2 Mvar	2000/5	96x96	SYT96E	1,2 Mvar
M132KU.	SYT96E 3000/5 1,8 Mvar	3000/5	96x96	SYT96E	1,8 Mvar
M132KV.	SYT96E 4000/5 2,4 Mvar	4000/5	96x96	SYT96E	2,4 Mvar
M132KW.	SYT96E 5000/5A 3 Mvar	5000/5	96x96	SYT96E	3 Mvar
M132L9.	SYT96AN 50/5A 30kvar	50/5	96x96	SYT96AN	30 kvar
M132LB.	SYT96AN 75/5A 50kvar	75/5	96x96	SYT96AN	50 kvar
M132LC.	SYT96AN 100/5A 60kvar	100/5	96x96	SYT96AN	60 kvar
M132LE.	SYT96AN 150/5A 90kvar	150/5	96x96	SYT96AN	90 kvar
M132LF.	SYT96AN 200/5 120kvar	200/5	96x96	SYT96AN	120 kvar
M132LH.	SYT96AN 300/5 180kvar	300/5	96x96	SYT96AN	180 kvar
M132LJ.	SYT96AN 400/5 240kvar	400/5	96x96	SYT96AN	240 kvar
M132LK.	SYT96AN 500/5 300kvar	500/5	96x96	SYT96AN	300 kvar
M132LL.	SYT96AN 600/5 360kvar	600/5	96x96	SYT96AN	360 kvar
M132LP.	SYT96AN 1000/5 600kvar	1000/5	96x96	SYT96AN	600 kvar
M132LR.	SYT96AN 1500/5 900kvar	1500/5	96x96	SYT96AN	900 kvar
M132LS.	SYT96AN 2000/5 1,2Mvar	2000/5	96x96	SYT96AN	1,2 Mvar
M132LU.	SYT96AN 3000/5 1,8Mvar	3000/5	96x96	SYT96AN	1,8 Mvar
M132LV.	SYT96AN 4000/5 2,4Mvar	4000/5	96x96	SYT96AN	2,4 Mvar
M132LW.	SYT96AN 5000/5A 3Mvar	5000/5	96x96	SYT96AN	3 Mvar

Creation date: 01/09/2026 - CIRCUTOR, SAU reserves the right to make technical changes or modify the content/images of this document without prior notice, in order to improve its reliability, functionality, design or for other reasons.
It accepts no liability for any errors, inaccuracies or possible lack of information in this document.