



YTC96E 400V .../5A

YTC96E 400V .../5A, Vattmeter

Code: M13232.

- > Scale: 90° P1
- > System: Balanced three-phase
- > Accuracy: 1,5
- > Measure: 400 Vph-ph, .../5 A
- > Device: YTC96E
- > Modules: 96x96

Description

- Does not need an auxiliary power supply
- DIN box with dimensions 96 and 144.
- Class 1.5
- Built-in electronic converter
- Balanced and unbalanced single and three-phase circuits.

Application

Measurement of the power factor in balanced or unbalanced single and three-phase circuits.



YTC96E 400V .../5A

Wattmeters and varmeters

Code: M13232.

Specifications

Mechanical characteristics

Size (mm) width x height x depth	96 x 96 x 49.2 (mm)
Fastening	Panel
Weight (kg)	0,29

YMC / YTC

Single-phase and three-phase varmeters

CODE	TYPE	Scale	Accuracy	Modules	Device	Measure
Single-phase						
M13231.	YMC96 400V .../5A	90° P1	1,5	96x96	YMC96	400 Vph-ph, .../5 A
M13241.	YMC144 400V .../5A	90° P1	1,5	144x144	YMC144	400 Vph-ph, .../5 A
Balanced three-phase						
M13232.	YTC96E 400V .../5A	90° P1	1,5	96x96	YTC96E	400 Vph-ph, .../5 A
M13242.	YTC144E 400V.../5A	90° P1	1,5	144x144	YTC144E	400 Vph-ph, .../5 A
Three-phase 3 wire (ARON)						
M13234.	YTC96A 110V .../5A	90° P1	1,5	96x96	YTC96A	110 Vph-ph, .../5A
M13244.	YTC144A 110V.../5A	90° P1	1,5	144x144	YTC144A	110 Vph-ph, .../5A
Three-phase 4 wire						
M13233.	YTC96AN 400V .../5A	90° P1	1,5	96x96	YTC96AN	400 Vph-ph, .../5 A
M13243.	YTC144AN 400V .../5A	90° P1	1,5	144x144	YTC144AN	400 Vph-ph, .../5 A

Exchangeable scales for types YMC 96, YTC 96E and YTC 96A. Scale not included (*1) Specify primary voltage and current of the measuring transformers, and power at full scale




YTC96E 400V .../5A

Wattmeters and varmeters

Code: M13232.

Dimensions



Connections

